

komfovent[®]



DOMEKT



INSTALLATION
MANUAL

EN

Content

1. SAFETY REQUIREMENTS 4

2. TRANSPORTATION AND STORAGE..... 5

3. BRIEF DESCRIPTION OF THE UNIT 7

4. INSTALLATION12

 4.1. Duct system installation.....15

 4.2. Condensate Drain Connections.....18

 4.1.1. Water trap installation for a unit section mounted on the suction side19

 4.1.2. Water trap installation for a unit section mounted on the pressure side19

 4.3. Heating coil connection.....24

 4.4. Final Inspection..... 25

5. MAINTENANCE..... 26

6. UNIT DIMENSIONS..... 28

 6.1. Vertical units 28

 6.2. Flat units..... 29

 6.3. Filters 30



This symbol indicates that this product is not to be disposed of with your household waste, according to the WEEE Directive (2002/96/EC) and your national law. This product should be handed over to a designated collection point, or to an authorised collection site for recycling waste electrical and electronic equipment (EEE). Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. At the same time, your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, waste authority, approved WEEE scheme or your household waste disposal service.

1. SAFETY REQUIREMENTS



The operation, maintenance or repair of the air handling unit is prohibited for people (including children) with mental, physical or sensory disabilities, as well as for persons without sufficient experience and knowledge, unless supervised and instructed by the person responsible for their safety in accordance with these instructions.



- To avoid accidents and/or unit damage, only a trained technician must carry out the connection.
- The appropriate Personal Protective Equipment (PPE) attire is worn relative to the operation being carried out.
- Electrical equipment is rated, connected and earthed in accordance with CE regulations.

The air handling unit must be plugged in to an electrical outlet (with earth), which is in good order and corresponds with all requirements of electric safety. Before starting any operations inside the unit, make sure that the unit is switched off, and the power cable is unplugged.




- Earth must be installed according to EN61557, BS 7671.
- The unit should be installed according to Installation and Maintenance Manual.
- Before starting the unit, check correct position of air filters.
- Service maintenance should be carried out only in conformity with the instructions specified herein below.
- If main cable is damaged, only manufacturer, service team or trained technician must change it in order to avoid accidents.
- Drilling and using self-tapping screws on the unit casing is prohibited (where it is not provided by the construction), since cables or tubes inside of the casing may be damaged.

2. TRANSPORTATION AND STORAGE

The air handling units are ready for transit and storage (1 Picture). The unit is packed to prevent damage of the external and internal parts of the unit, dust and moisture penetration.

Corners of the air handling units are protected against the damage – protective corners are used. The entire unit is wrapped up in protective film. For transit or storage, units are mounted on timber pallets. The unit is fastened to the pallet with polypropylene packing tape over protective corners.

Vertical and horizontal units ready for transit and storage




1 Picture

When unit is loaded or unloaded by crane, cargo rope is fastened in its designated places.

Forklift truck or hand pallet truck can transport air handling unit as it is shown (2 a, b, c Pictures).

Vertical and horizontal unit transportation by forklift truck, hand pallet truck or crane



- 2a Unit is transported by forklift truck on a wooden pallet;
 2b Unit is transported by hand pallet truck on a wooden pallet;
 2c Unit is lifted by crane on a wooden pallet.

The unit should be examined upon receipt, to ensure that no visible damage has occurred during transit, and the advice note checked to ensure that all items have been received. If damage or delivery shortages are discovered, the carrier should be immediately informed. KOMFOVENT should be notified within three days of receipt, with a written confirmation sent within seven days. KOMFOVENT can accept no responsibility for damage by unloading from carrier or for subsequent damage on site.

If the unit is not to be installed immediately, it should be stored in a clean, dry area. If stored externally, it should be adequately protected from the weather.

3. BRIEF DESCRIPTION OF THE UNIT

- The air handling units are intended for ventilation of small and medium-sized spaces (eg. single family houses, offices, etc.), having operating ambient temperature and relative humidity. The unit is intended to be installed in the domestic or non residential premises. Mineral wool is used for thermal insulation and sound attenuation. Units cover panels are 25–50 mm thick. As standard, the unit is designed for indoor placement. In cold, wet rooms possible icing or condensation on the housing inside and outside. The operating temperature range for the unit is -30 °C ... +40 °C, outdoor air temperature. Extracted indoor air temperature +10 – +40 °C, relative humidity (non-condensing) 20–80 %.
- The air handling unit is not to be used to transport solid particles, even not in areas where there is a risk of explosive gases.
- Inside of the air handling unit it is integrated heat-exchanger and heater (or cooler), which compensates losses of the heat/cold during ventilation of the premises, thus AHU is not recommended to be used as main heating/cooling source of the building. AHU may not reach the supply temperature setpoint if the actual room temperature differs a lot from the desired value, since in that case heat exchanger capacity will be low.
- Before you open the door, the unit must be switched off and the fans must have been given time to stop (up to 3 minutes).
- The unit contains heating elements that must not be touched when they are hot.
- We recommend to leave air handling unit in working mode (minimum 20 percent of power) during the first operation year. Due to moisture in building constructions, condensation may occur inside and outside the air handling unit. Continuous operation of the equipment will significantly reduce the risk of condensation.
- Under conditions, when the outdoor air temperature is low and humidity is high, risk of heat exchanger frosting may appear. For this reason anti-frost protection function is foreseen in the controller of the Komfovent air handling units. Depending on the type of the air handling unit, different methods of anti-frost protection are available: cold air by-passing, supply air fan speed reducing and/or integrated preheater. Counter cross flow heat exchanger is the mostly sensitive for low outside air temperatures, as the risk of frosting appears in the temperature range from 0 to -5 °C and below. Standard aluminium cross-flow plate heat exchanger has better features, as the risk of freezing appears only at -10 °C. The lowest risk and the highest resistance to cold outside air is a competitive feature of the rotary heat exchanger, as it is not freezing even at the temperatures of -30 °C if the humidity level of the air is appropriate.




In the units with counter flow or cross flow plate exchangers without integrated pre-heater, it is necessary to install additional duct mounted preheater in the outside air intake duct, which will ensure temperature of the intake air higher than -4 °C.

- Selecting the management without pre-heater, but with cold air bypass the unit must be additionally equipped with a secondary duct mounted heater.

If the unit is mounted in premises with high humidity, condensation might occur on the surface of the unit when outdoor temperatures are low (see picture 3). When installing unit in such a premises, it is necessary to take additional measures, to avoid condensate damage to the building construction elements or furniture.

From the diagram in picture 3, it can be checked under what conditions condensate might appear on the unit external surfaces.



Example No. 1

Temperature of the premises 20°C
Relative humidity of the premises 40%
Condensate will occur when outdoor temperature is lower than -19°C

Example No. 2

Temperature of the premises 22°C
Outdoor temperature -10°C
Condensate will occur when relative humidity of the premises will be higher than 50%

Example No. 3

Relative humidity of the premises 55%
Outdoor temperature 0°C
Condensate will occur when temperature of the premises will be higher than 26°C

3 picture. Condensation on unit surface diagram

To minimize possibility of condensation on unit outer surfaces use following recommendations:

- 1) Ensure proper ventilation of the room where the AHU is installed.
- 2) Maintain lower relative humidity in the room where air handling unit is mounted.
- 3) Preheater should be installed to increase the supply air temperature.



It is recommended to keep air handling unit constantly running and in cases when ventilation is not necessary, switch it to the minimum intensity (20%). In that way, good indoor climate will be maintained and condensation inside of the unit will decrease, avoiding humidity damage to electronic components.








It is forbidden to install DOMEKT air handling units outdoors. They are also not designed for ventilation or dehumidification of humid premises (swimming pools, baths, car washes, etc.).




Make sure that children will not reach and will not play with air handling unit without adult supervision.

Air Handling Units Schemes







DOMEKT CF 250 F





DOMEKT CF 400 V



DOMEKT CF 500 F



DOMEKT CF 700 V



1. Rotary or plate heat exchanger
2. Electric or water air heater
3. Supply air filter
4. Exhaust air filter
5. Supply fan
6. Exhaust fan
7. Air by-pass damper
8. Condensate drain
(the water trap must be installed)

- ODA** – outdoor air
- SUP** – supply air
- ETA** – extract air
- EHA** – exhaust air
- ETB** – by-pass extraction without heat recovery

4. INSTALLATION


It is recommended to install the air handling unit in a separate room or in the attic on a hard smooth surface insulated with a rubber mat. The minimum free space in front of the control panel should be not less than 700 mm. The free space over the top of the unit should be at least 300 mm (4 a, b Picture). Rubber vibration absorbers must be used when unit is going to be mounted on the wall or ceiling.

Some DOMEKT units can be suspended on the wall, and flat units can be attached to the ceiling. Special brackets, wall screws with plastic bushings and self-tapping screws are provided for mounting the units. When mounting the units, care must be taken to ensure that vibrations of the unit are not transmitted to the building structures, as it may lead to additional noise. In order to eliminate vibrations, additional anti-vibration gaskets are attached to the back wall of the unit. Some units are supplied with factory fitted anti-vibration gaskets; in other cases, they are supplied separately. In case of ceiling-mounted units, vibration absorbers are integrated in mounting brackets.

The place for the unit must be selected with allowance for minimum access to the unit for maintenance or service and must comply with safety requirements. Opening for inspection can not be smaller than dimensions of the unit and unit itself must be mounted in a way, that if needed (for example in case of complicated repair) it can be easily dismantled.


When mounting on the floor, we recommend not to rest the unit against the wall to prevent noise or vibration and accumulation of moisture or mould on the wall due to condensation.

Installation of the floor mounted horizontal unit. Maintenance space.





4a Picture

Installation of the floor mounted vertical unit. Maintenance space.




4b Picture

Unit Installation Scheme




1. Air handling unit
2. Air duct connections
3. Sound attenuator
4. Drain siphon (if provided)
5. Rubber vibration absorber (not included in unit set)

4 Picture



5a Picture*




5b Picture**

* Only F type units


** Only R 250 F, S 800 F HW, S 1000 F HW units.

DOMEKT CF 250F – CF 500F – CF 700F Units brackets' positions




6 Picture

DOMEKT CF 400 V Unit brackets' positions




7 Picture

Pictures 7a and 7b show unit's upper and bottom fixing element.



7a Picture



7b Picture

1. Screw
2. Wall plug
3. Hanging bracket 1
4. Hanging bracket 2
5. Bolt M5


6. Gasket
7. Self tapping screw
8. L-shape bracket
9. Washer M5 DIN9021

4.1. Duct system installation

The air in and out of the unit flows through the duct system. The duct system should be designed and selected to have low airflow rates and low pressure differentials, ensuring more accurate airflow rates, lower energy consumption, lower noise levels and longer life of the unit.

Outdoor vents must be installed as far apart as possible on different sides of the building to prevent the exhaust air from returning to the air intakes. Try to install the air intake vents where the outdoor air is the cleanest: do not direct them towards the street, car park or outdoor fireplace. We also recommend installing the air intake vent on the north or east side of the building, where the heat of the sun in summer will not have a significant effect on the supply air temperature.

It is highly recommended to install unit connecting ducts of supply inlet and exhaust outlet with a minimum slope on the outside of the premise, to avoid water flowing into the unit in case of rain or snow.



It is recommended to insulate the ducts in unheated rooms (attic, basement) to avoid heat loss. It is also recommended to insulate the supply air ducts if the unit is used for room cooling.

The air ducts are fitted to the unit with self-tapping screws. Different air flow duct positions are marked on the sticker located on the AHU:




Fig. 8. Air duct marking

Most units with a rotary heat exchanger also have a fifth branch (labelled E) to connect an additional exhaust duct (see „Air Handling Units Schemes“). The airflow through this opening is delivered directly to the exhaust fan, bypassing the filters and heat exchanger, therefore, you can connect ducts from the bathroom, toilet, or kitchen in cases when there is no additional extraction fan in these premises. However, air is extracted through an additional branch without recuperation, thus reducing the efficiency of the heat exchanger. For this reason, we do not recommend using the extra air extraction continuously. An additional exhaust duct should be fitted with air closing damper (motorized are recommended) and should only be opened when additional extraction is required (e.g. when bathing). If the additional branch is connected to the kitchen hood with an integrated closing damper, an additional damper is not needed.




Fig. 9. Example of mounting of an additional air extraction duct

Note: temperature sensor B1 has to be mounted in the supply air duct under electric heater (see the functional diagram in Control System Electrical Installation and Operation Manual). It is necessary to leave space in straight air duct for sensor mounting and guarantee the space for maintenance and service work. Minimal space between the unit and B1 sensor is the space of double air duct diameter.



- Ducts connecting the unit to the exterior of the building must be insulated (insulation thickness 50–100 mm) to prevent condensation on cold surfaces.
- Air intake and exhaust ducts must be fitted with air closing dampers (mechanical spring-loaded or electric with actuators) to protect the unit from exposure to climatic conditions when the unit is switched off.
- In order to minimise AHU noise transferring through the ducts into ventilated areas, sound attenuators must be connected to the unit.
- Duct system elements must have separate brackets and to be mounted in a way that their weight is not shifted to the unit casing.
- The kitchen hood with integrated exhaust fan must not be connected to the additional air exhaust duct. Such hood must be connected to a duct separated from the general ventilation system.

The diameter of the ducts varies by unit model:

		Unit									
		DomektR 190 V DomektR 200 V	DomektR 300 V	DomektR 250 F	DomektR 500 V DomektR 700 V	DomektCF 250 F DomektCF 400 V	DomektCF 500 F DomektCF 700 V	DomektCF 700 F	DomektS 650 F	DomektS 800 F	DomektS 1000 F
Duct diameter, mm	ODA	125	160	160	250	160	200	250	160	200	250
	SUP	125	160	160	250	160	200	250	160	200	250
	ETA	125	160	160	250	160	200	250	-	-	-
	EHA	125	160	160	250	160	200	250	-	-	-
	ETB	125	100	125	125	-	-	-	-	-	-


4.2. Condensate Drain Connections

All condensate drain connections must be correctly trapped. Incorrect trapping can result in flooding within the unit and consequent flooding of the immediate area. Fill the drain trap with water before starting up the unit.

All drain lines should be insulated where passing through any space where damage from condensation drip might occur. If the unit is installed in unheated premises the condensate pipe should be heat-insulated and heated with heating cable.


A condensate pipe and a drain trap

Drain scheme of Vertical Unit



10a Picture

Drain scheme of Horizontal Unit




10b Picture

The bend of the water trap can be repositioned by turning it to the right or the left. The drain line from the water trap must be arranged so that it will not damage adjacent unit sections or building elements. If the drain line is run through cold spaces, it should be insulated to prevent freezing. A heating cable may be required.

4.1.1. Water trap installation for a unit section mounted on the suction side

Since the fans in most air handling units are last in the chain of functions and generate sub-atmospheric pressure inside the unit, it is very important to correctly install the water trap. Because of that reason condensate can be hardly eliminated from the air handling unit and the technical premise may get covered with condensate. Height H_1 must be at least equivalent in mm to half of the negative pressure inside the unit in mm water gauge. Height H_2 must be at least equivalent in mm to the negative pressure inside the unit in mm water gauge.



Precaution: The drainage siphon should be mounted on the outlet fitting pipe of every drip tray for complete condensate drainage from the air handling unit and prevention of penetration of offensive odours from an effluent into the ventilation system.



In case of the outdoor operation of the air handling unit, the siphon and the bleeders should be heated with an electric thermal cable (if ambient air temperature $t_{amb} < 0^\circ\text{C}$). The siphon and the bleeders should be heat-insulated with an insulating material.


4.1.2. Water trap installation for a unit section mounted on the pressure side

Since the fans in most air handling units are not last in the chain of functions and generate over-atmospheric pressure inside the cooling section. In such case the consisted condensate can be easily removed from AHU and there will be no strict requirements for siphon's installation. A drainage siphon is enough with a minimum rake.

RECOMMENDATION: The drainage siphon must be installed in connection with not less size pipe diameter.


Any drainage systems must not be connected directly to the municipal sewage system. The condensate tray shall be easily accessible for cleaning and disinfection.

DOMEKT R 190V / 200V unit inspection side change



SUP – Supply air duct connection.



DOMEKT R 190V / 200V Unit hanging scheme without kitchen hood



1. Air handling unit DOMEKT R 190V / 200V
2. Wall plug 8x50 + screw 4,5x50
3. Wall mounting bracket
4. Self tapping screw 4,2x13
5. Unit bracket
6. Bottom bracket
7. Screw M4x16 (DIN 7895)
8. Bracket for decorative panel
9. Screw 2.5x16 with cone head

DOMEKT R 190V / 200V unit with kitchen hood


Air handling unit DOMEKT R 190V / 200V can be mounted with one of the two types of kitchen hoods (11, 12 Picture).



1. Air handling unit DOMEKT R 190V / 200V
2. Kitchen hood adapter 392-12
3. Kitchen hood 392-12
4. Standard kitchen hood
5. Wall plug 8x50 + screw 4,5x50
6. Wall mounting bracket
7. Unit bracket
8. Self tapping screw 4,2x13
9. Bracket for decorative panel
10. Screw 2.5x16 with cone head


11 Picture

Dimensions for mounting furniture panel




Installation scheme of DOMEKT R 190V / 200V unit with kitchen hood


Before installing kitchen hood, bottom cover plate must be removed by removing fixing screws (2a pic.)



Dimensions for the DOMEKT R 190V / 200V installation space




13 Picture. Dimensions with standard kitchen hood



14 Picture. Dimensions with kitchen hood 392-12

DOMEKT R-300V Unit hanging scheme




1. Wall plug 8×50
2. Screw 4,5×50
3. Upper bracket
4. Fixing bolt M5×30
5. Self tapping screw 4,2×13
6. Lower bracket
7. Adhesive anti-vibration gasket
8. Self tapping screw 4,2×13 (optional)

15 Picture

4.3. Heating coil connection¹

Pipe work should be connected in accordance with good engineering practice. All pipe work must be adequately supported to ensure that no additional load is stressing the unit. Mounting the pipes on the heating coil, tight the pipes with spanners. As shown in 16 Picture. If water is used in the heater, for frost protection water temperature sensor (B5), must be installed and fixed with strap on the return water pipe as close to the heater as possible. Fix the sensor in a way that its metal part has good contact with a surface of the pipe.



16 Picture. Connecting the water heater/cooler hoses and installing the water temperature sensor

¹ If water heater build in.

The pipe work should be done in order to ensure the space for maintenance and service work. When carrying out the installation of heater pipes, make sure that hot water supply is completely disconnected. Before start-up of the air handling unit, the heater system should be filled in with water. Glycol is used in the air handling units with coil heat exchanger. Never pour glycol down a drain; collect it in a receptacle and leave it at a recycling centre or the like. Glycol is highly dangerous to consume and can cause fatal poisoning or damage the kidneys. Contact a doctor! Avoid breathing glycol vapour in confined spaces. If you get glycol in your eyes, flush them thoroughly with water (for about 5 minutes).



When operating air handling unit in the temperatures lower than 0 °C, it is necessary to use glycol additionally or assure the reversible heating agent temperature more than 25 °C.



Pipework package¹ must include circulation pump, which circulates heating/cooling medium through the coil (smaller circuit) and 3-way mixing valve with modulated actuator. In cases if 2-way valve is used, additionally it must be installed non-return valves to ensure continuous circulation around smaller circuit. PPU must be installed as close to the water coil as possible.



It is important to maintain air heaters and coolers cleanliness; that is to change filters installed in the air handling unit on time. If the air heater or cooler gets dirty, to perform periodical cleaning.

4.4. Final Inspection

After installation of the unit, a thorough inspection should be carried out. This should include inspecting the inside of the unit and removing debris and tools, which may have been left behind by on site contractors. Replace any panels, which may have been removed and close all access doors, ensuring that the door sealing gaskets have not been damaged.

¹ It is recommended to use PPU made by Komfovent.

5. MAINTENANCE

It is recommended to carry out routine maintenance of the air handling unit 3–4 times per year. With units mounted on ceiling do not release the door to the key to open the door. Do not release the door to swing freely, but open it slowly at a 90 degree angle. Be careful while opening, because clogged filters might fall out.



The operation, maintenance or repair of the air handling unit is prohibited for people (including children) with mental, physical or sensory disabilities, as well as for persons without sufficient experience and knowledge, unless supervised and instructed by the person responsible for their safety in accordance with these instructions.

Besides preventive maintenance inspection, the following operations should be performed:

1. **Rotary heat exchanger check.** Inspection of the rotary heat exchanger is performed once per year. Free rotation of the rotary heat exchanger, continuity of the rotating belt, absence of damages of the rotor drums and the seal gasket are checked. It is necessary to check the stretch of belt. Free belt will slide and the efficiency of rotary heat exchanger will fall down. To reach maximal efficiency, rotor must turn at least 8 times per minute. Polluted heat exchanger will decrease efficiency. Clean heat exchanger with an air blast or wash with tepid water. Check out water falling on the electric motor.

2. **Plate heat exchanger check.** Inspection and dedusting of the plate heat exchanger is performed once per year (it is removed from the unit and blown with an air blast or washed with tepid water).

Plate heat exchanger cleaning. If plate heat exchanger cleaning by compressed air is not effective, it can be washed with soapsuds, or if needed – use degreasing soak for metal (aluminum) cleaning. Leave plate heat exchanger to dry in a warm place. It can be mounted only when it is absolutely dry.

Note: plate heat exchanger may be replaced with summer cassette (for units without by pass), when recuperation is needless.

3. **Fans check (once per year).** Polluted fans decrease efficiency.



Before performing any inspection work, check whether the unit is switched off from the electric power supply.

Fans should be carefully cleaned with textile or soft brush. Do not use water. Do not break balance. Check if direction of fan turns is right, because wrong direction of turns gives only 30 % rating. Check if fan freely rotates and is not mechanically damaged, if impeller does not touch suction nozzles, fan does not spread noise, the pressure tubes are connected to the nozzle (if it is required), mounting bolts are screwed.


The rubber couplings connecting the motor base and the unit should be visually inspected for signs of wear and replaced as necessary.

Any unusual noise or vibration when the fan is running should be immediately investigated, as this usually an indication of wear or imbalance in the fan system.

4. **Air heater check.** Recommended to perform periodical inspection and cleaning of heater. Check the plates of water air heater. The air heater is cleaned with Hoover from supply air side or with air blast from exhaust air side. If it is very dirty, wash with tepid water, which will not make corrosion of aluminium. Check if position of return water temperature sensor is right. Check if electric air heater is properly fixed, wires connections are not damaged and heating elements are not bent. They can be damaged or bent due to uneven heat or uneven and turbulent air direction. Check if electric air heater is clear of unnecessary things and heating elements are not clogged, because this can cause unpleasant smell or in the worst case – dust can start burning. Air flow through the air heater should be greater than 1,5 m/s. Heating elements can be cleaned with Hoover or wet textile.

5. **Air damper check (if it is required).** Not fully opened outside air damper rises up the pressure in the system. Water air heater can freeze if outside air damper does not fully close in not working air handling unit. Mounting and running of air damper should be checked and regulated.
6. **Air filter clogging check.** Change air filters when air filter clogging is indicated. We recommend changing filters at least twice per year: before and after heating season or more¹. Filters are one time used. We do not recommend cleaning them. Stop the air handling unit before changing filters.

Pressure sensor



17 Picture



7. **Pressure sensor setting, which indicates impurity of filters².** Pressure sensor is set according to EN 13779:2007 standard: 100 Pa for small systems, 150 Pa for big systems. Remove cover from the pressure sensor and turn the cursor due to proper position. The indicator will turn on when filters will be clogged.
- One of pressure sensors shown in 17 Picture can be mounted in the air handling unit.
 - Close the door after pressure sensor regulating process. Be sure that sensor does not indicate impurity of clear filters.
 - Pressure sensors in the air handling units up to size 900 are regulated and set in factory.

¹ Clogged filters unbalance ventilation system, air handling unit uses more power.

² Only on DOMEKT S units.


6. UNIT DIMENSIONS

6.1. Vertical units




Unit	Ins- pection side	Dimensions, mm														
		H	H1	L	B	b1	b2	b3	b4	l1	l2	l3	l4	h5	e1	e2
DOMEKT R (C4)																
190 V 200 V	Right	660	625	600	325	95	230	95	230	81	226	226	81	-	81	95
	Left	660	625	600	325	95	230	95	230	81	226	226	81	-	519	230
DOMEKT R (C6)																
300 V	Right	615	615	605	515	195	330	115	330	102	290	102	102	-	302	82
	Left	615	615	605	515	195	330	115	330	102	290	102	102	-	302	82
500 V	Right	966	950	1070	645	229	415	229	415	418	190	190	418	-	418	166
	Left	966	950	1070	645	229	415	229	415	418	190	190	418	-	652	479
700 V	Right	966	950	1070	645	229	415	229	415	418	190	190	418	-	418	166
	Left	966	950	1070	645	229	415	229	415	418	190	190	418	-	652	479
DOMEKT CF (C6)																
400 V	Right	764	750	598	600	112	382	112	382	139	139	139	139	50	-	-
	Left	764	750	598	600	112	382	112	382	139	139	139	139	50	-	-
700 V	Right	1146	1130	1020	495	165	325	165	325	155	410	410	155	90	-	-
	Left	1146	1130	1020	495	165	325	165	325	155	410	410	155	90	-	-

6.2. Flat units



Unit	Ins- pection side	Dimensions, mm											
		H	L	L1	B	B1	b1	b2	b3	b4	h1	e1	e2
DOMEKT R (C6)													
250F	Right	310	871	842	618	602	200	150	150	200	146	245	104
	Left	310	871	842	618	602	150	200	200	150	146	597	104
DOMEKT CF (C6)													
250F	Right	294	1278	1250	604	604	142	162	192	162	134	-	-
	Left	294	1278	1250	604	604	192	162	142	162	134	-	-
500F	Right	295	1430	1400	1045	1045	277	239	277	316	135	-	-
	Left	295	1430	1400	1045	1045	277	316	277	239	135	-	-
700F	Right	344	1394	1365	875	875	266	234	204	234	159	-	-
	Left	344	1394	1365	875	875	204	234	266	234	159	-	-

Units Domekt S



Unit	Dimensions, mm							
	H	L	L1	B	b1	b2	h1	h2
DOMEKT S (C5)								
650F	297	905	873	475	237,5	237,5	120	120
800F	360	1005	973	475	237,5	237,5	152	152
1000F	350	925	893	700	350	350	152	152

6.3. Filters

Unit	Type	Supply		Exhaust	
		Class	B×H×L, mm	Class	B×H×L, mm
Domekt R 190 V Domekt R 200 V	Compact	ePM1 55% (F7)	285×130×46	ePM10 50% (M5) *	285×130×46
Domekt R 250 F	Compact	ePM1 55% (F7)	278×258×46	ePM10 50% (M5) *	278×258×46
Domekt R 300 V	Compact	ePM1 55% (F7)	290×205×46	ePM10 50% (M5) *	290×205×46
Domekt R 500 V Domekt R 700 V	Compact	ePM1 55% (F7)	540×260×46	ePM10 50% (M5) *	540×260×46
Domekt CF 250 F	Compact	ePM1 55% (F7)	265×250×46	ePM10 50% (M5) *	265×250×46
Domekt CF 400 V	Compact	ePM1 55% (F7)	350×235×46	ePM10 50% (M5) *	350×235×46
Domekt CF 500 F	Compact	ePM1 55% (F7)	484×250×46	ePM10 50% (M5) *	484×250×46
Domekt CF 700 V	Compact	ePM1 55% (F7)	390×300×46	ePM10 50% (M5) *	390×300×46
Domekt CF 700 F	Compact	ePM1 55% (F7)	400×300×46	ePM10 50% (M5) *	400×300×46
Domekt S 650 F	Compact	ePM1 55% (F7)	371×235×46	-	-
Domekt S 800 F	Compact	ePM1 55% (F7)	371×287×46	-	-
Domekt S 1000 F	Compact	ePM1 55% (F7)	558×287×46	-	-

* ePM1 55% (F7) class filter is available as an option.

SERVICE AND SUPPORT

LITHUANIA

UAB KOMFOVENT

Phone: +370 5 200 8000
service@komfovent.com
www.komfovent.com

SWEDEN

Komfovent AB

Ögärdesvägen 12A
433 30 Partille, Sverige
Phone: +46 31 487 752
info_se@komfovent.com
www.komfovent.se

FINLAND

Komfovent Oy

Muuntotie 1 C1
FI-01 510 Vantaa, Finland
Phone: +358 20 730 6190
toimisto@komfovent.com
www.komfovent.com

GERMANY

Komfovent GmbH

Konrad-Zuse-Str. 2a,
42551 Velbert, Deutschland
Phone: +49 0 2051 6051180
info@komfovent.de
www.komfovent.de

LATVIA

SIA Komfovent

Bukaišu iela 1, LV-1004 Riga, Latvia
Phone: +371 24 66 4433
info.lv@komfovent.com
www.komfovent.com

Vidzemes filiāle

Alejas iela 12A, LV-4219 Valmiermuiža,
Valmieras pagasts, Burtnieku novads
Phone: +371 29 358 145
kristaps.zaicevs@komfovent.com
www.komfovent.com

UNITED KINGDOM

Komfovent Ltd

Unit C1 The Waterfront
Newburn Riverside
Newcastle upon Tyne NE15 8NZ, UK
Phone: +447983 299 165
steve.mulholland@komfovent.com
www.komfovent.com

PARTNERS

AT	J. PICHLER Gesellschaft m. b. H.	www.pichlerluft.at
BE	Ventilair group ACB Airconditioning	www.ventilairgroup.com www.acbairco.be
CZ	REKUVENT s.r.o.	www.rekuvent.cz
CH	WESCO AG SUDCLIMATAIR SA CLIMAIR GmbH	www.wesco.ch www.sudclimatair.ch www.climair.ch
DK	Øland A/S	www.oeland.dk
EE	BVT Partners	www.bvtpartners.ee
FR	ATIB	www.atib.fr
HR	Microclima	www.microclima.hr
HU	AIRVENT Légtechnikai Zrt. Gevent Magyarország Kft. Merkapt	www.airvent.hu www.gevent.hu www.merkapt.hu
IR	Fantech Ventilation Ltd	www.fantech.ie
IS	Blikk & Tækniþjónustan ehf Hitataekni ehf	www.bogt.is www.hitataekni.is
IT	Icaria srl	www.icariavmc.it
NL	Ventilair group DECIPOL-Vortvent CLIMA DIRECT BV	www.ventilairgroup.com www.vortvent.nl www.climadirect.com
NO	Ventilution AS Ventistål AS Thermo Control AS	www.ventilution.no www.ventistal.no www.thermocontrol.no
PL	Ventia Sp. z o.o.	www.ventia.pl
SE	Nordisk Ventilator AB	www.nordiskventilator.se
SI	Agregat d.o.o	www.agregat.si
SK	TZB produkt, s.r.o.	www.tzbprodukt.sk
UA	TD VECON LLC	www.vecon.ua