



VP	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
Control panel	MODBUS RS485 connection	External control	External stop	Fire system	OR control	Common	Return water temp. sensor	B5	B1	Supply temp. sensor	Humidifier control	DX 0-10V control	Hot water mixing valve actuator	S2	S1	Humidity sensor	B9	B8	B7	B6	Supply/return air damper actuator	Run	Alarm	Common	Heating	Operation	Common	Water pump/cool alarm																				