komfovent

SQR

WALL MOUNTED, SENSORY, AIR QUALITY, HUMIDITY AND TEMPERATURE SENSOR-CONTROLLER

AQ ventilation intensity control option depends on the external sensor signal. Provides ventilation intensity correction according to the increased CO_2 , humidity level, etc. A different AQ function may be set depending on the sensor type, therefore, the intensity of the unit will be regulated accordingly. User can activate this function anytime according to the demand and can also observe the premise's air quality on the panel. This function is possible for all the units with EC fans just by connecting one of the sensors listed below.



Туре	Parameters	Code
Wall mounted, sensory, air quality, humidity and temperature sensor-controller "SQR"	 Supply voltage: 24 Vac / 24 Vdc ±20 % VOC: 0100 % Relative humidity: 0 % 100 % Temperature: 0 °C 50 °C 2 selectable output signal: 010 V RS-485 Modbus interface Relay output for on/off control Adjustable setpoint for VAV control Protection class: IP30 Dimensions: 80 × 80 × 26 mm 	1034822